



# Sony Alpha NEX-6 Lens Replacement

A quick and easy guide to managing the camera lens.

Written By: Clayton Dale



## INTRODUCTION

This guide provides a step-by-step procedure for safely removing the lens of a Sony Alpha NEX-6 camera.

## Step 1 — Finding the Release Button



- Turn the camera with the lens facing **up**.
- Find the *lens release button* - located along the side of the *silver lens mount*.

## Step 2 — Removing the Lens



- Press and hold the *lens release button* while rotating the lens **counterclockwise**.
- Lift the lens when it is no longer attached to the camera.
- ☑ To replace the lens, align the white dot on the lens with the white dot located on the silver lens mount. (See image two)
- ☑ Insert the lens and rotate it clockwise until it is locked in place.

The procedure to disassemble this lens is different from reassembly. This guide encompasses both processes.

This document was last generated on 2017-11-21 09:59:20 PM.